

TWS (knots)	Main top batten	Headsail	Spinn.	Headstay turnbuckle	Mast rake	V's Loos	V's mm	D1's Loos	D1's mm	D2's Loos	D2's mm	Butt pos.
22+	Std	3½	S4	-4 Full turns	229	79		43		46		178
18-22	Std	MH	S4	-3 Full turns	228,5	79		41		42		178
16-20	Std	MH	S4	-2 Full turns	228	77		39		42		178
12-16	Std	MH	S4	-2 Full turns	228	77		37		38		178
<b>08-12</b>	<b>Soft</b>	<b>LM</b>	<b>S1,5</b>	<b>Base</b>	<b>227</b>	<b>74</b>		<b>35</b>		<b>36</b>		<b>178</b>
04-08	Soft	LM	S1,5	+2 Full turns	228	72		33		36		178
						All adjustments are in reference to base.		Use Loosegauge RT-10M		Use Loosegauge PT-2M		

Latest update: 11.05.2006

## Rig setup



**1+2 Mastbutt position:** Measure 178 mm from aft edge mast to main bulkhead. **3. Headstay datum:** Top bas swing to forestay with center halyard to intersection deck/forestay. **4. Mark your headfoil** and use same mark as halyard tension. Mark the lufftape on your headsail and use that as reference mark. **5. Measure** from mark on headfoil to the intersection deck/forestay. Base setting 227 mm. Adjust according to wind speed. All adjustments are in reference to base.

**Deck position for mast:** Centerline intersection deck/forestay to forward edge mast = 4190mm. **Headstay turnbuckle:** 2 Full turns = 1 cm. **Spreader trim dots: S1:** 50-60-70-80 cm (measured from centre verticals). **S2:** 30-40-50 cm (measured from centre verticals)

Date	TWS	Main bat.	Headsail	Spinn.	Headstay turnbuckle	Rake	V's Loos	V's mm	D1's Loos	D's mm	D2's Loos	D2's mm	Butt pos.



INVENTORY BY NORTH SAILS  
 Better by Design